

FROM POWER SOURCE SYSTEM (SEE PAGE 52)
10A TURN
15A HORN
H 6 HAZARD SW
HAZARD
OFF
ON
C14 TURN SIGNAL SW [COMB. SW]
TURN
RH
LH
TURN SIGNAL FLASHER
R-B
L-W
G
L-R
G-B
G-Y
G-W
L-R
R-L
W-B
R 6 REAR TURN SIGNAL LIGHT LH [REAR COMB. LIGHT LH]
F 3 FRONT TURN SIGNAL LIGHT LH
F 4 FRONT TURN SIGNAL LIGHT RH
R 7 REAR TURN SIGNAL LIGHT RH [REAR COMB. LIGHT RH]
J 1 JUNCTION CONNECTOR
C12 TURN SIGNAL INDICATOR LIGHT [COMB. METER]
LH
RH
B 7
I 6
IG
EA
IE

SERVICE HINTS

TURN SIGNAL FLASHER [J/B NO. 1]

3–GROUND: Approx. **12** volts with ignition SW on or hazard SW on

1–GROUND: Changes from **12** to **0** volts with ignition SW on and turn signal SW left or right, or with hazard SW on

○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
C12	30	F 4	26 (5VZ–FE)	R 6	32
C14	30		28 (3RZ–FE, 2RZ–FE)	R 7	32
F 3	26 (5VZ–FE)	H 6	31		
	28 (3RZ–FE, 2RZ–FE)	J 1	31		

⬭ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
2	19	R/B No. 2 (Engine Compartment Left)

⬭ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	20	Cowl Wire and J/B No. 1 (Lower Finish Panel)
1C		
1F	20	Engine Room Main Wire and J/B No. 1 (Lower Finish Panel)
3F	22	Cowl Wire and J/B No. 3 (Behind the Instrument Panel Left)

▭ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
BN1	41	Frame Wire and Cowl Wire (Under the Driver's Seat)


▽ : GROUND POINTS

Code	See Page	Ground Points Location
EA	34 (5VZ–FE)	Front Left Fender
	36 (3RZ–FE, 2RZ–FE)	
IE	38	Around the Right Edge of the Reinforcement
IG	38	Around the Left Edge of the Reinforcement


⬡ : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I 6	38	Cowl Wire	B 7	40	Frame Wire


C12 BLUE




C14




F 3, F 4 GRAY



H 6 BLACK



J 1 GRAY



(Hint:See Page 7)

R 6, R 7

